

## HELICAL-BEVEL GEAR UNIT (B-K..)

B-K.., B-KA..B, B-KV..B, B-KH..B

Model	Fill Quantity (L)					
	M1	M2	M3	M4	M5	M6
B-K..37	0.5	1	1	1.3	1	1
B-K..47	0.8	1.3	1.5	2	1.6	1.6
B-K..57	1.2	2.3	2.5	3	2.6	2.4
B-K..67	1.2	2.4	2.6	3.4	2.6	2.6
B-K..77	2.2	4.1	4.4	5.9	4.2	4.4
B-K..87	3.7	8	8.7	10.9	7.8	8
B-K..97	7	14	15.7	20	15.7	15.5
B-K..107	10	21	25.5	33.5	24	24
B-K..127	21	41.5	44	54	40	41
B-K..157	31	62	65	90	58	62
B-K..167	35	100	100	125	85	85
B-K..187	60	170	170	205	130	130

B-KF..

Model	Fill Quantity (L)					
	M1	M2	M3	M4	M5	M6
B-KF..37	0.5	1.1	1.1	1.5	1	1
B-KF..47	0.8	1.3	1.7	2.2	1.6	1.6
B-KF..57	1.3	2.3	2.7	3	2.9	2.7
B-KF..67	1.2	2.4	2.8	3.6	2.7	2.7
B-KF..77	2.1	4.1	4.4	6	4.5	4.5
B-KF..87	3.7	8.2	9	11.9	8.4	8.4
B-KF..97	7	14.7	17.3	21.5	15.7	16.5
B-KF..107	10	22	26	35	25	25
B-KF..127	21	41.5	46	55	41	41
B-KF..157	31	66	69	92	62	62

B-KAF.., B-KVF.., B-KAZ.., B-KVZ.., B-KA..

Model	Fill Quantity (L)					
	M1	M2	M3	M4	M5	M6
B-K..37	0.5	1	1	1.4	1	1
B-K..47	0.8	1.3	1.6	2.1	1.6	1.6
B-K..57	1.3	2.3	2.7	3	2.9	2.7
B-K..67	1.2	2.4	2.7	3.6	2.6	2.6
B-K..77	2.1	4.1	4.6	6	4.4	4.4
B-K..87	3.7	8.2	8.8	11.1	8	8
B-K..97	7	14.7	15.7	20	15.7	15.7
B-K..107	10	20.5	24	32	24	24
B-K..127	21	41.5	43	52	40	40
B-K..157	31	66	67	87	62	62
B-K..167	35	100	100	125	85	85
B-K..187	60	170	170	205	130	130